


**Pelatore universale-pelapatate-lavacozze mod. PLN-PPN-LCN10-18**  
**Universal peeler-potato peeler-mussel washer mod. PLN-PPN-LCN10-18**



**PELATORE UNIVERSALE-PELAPATATE-LAVACOZZE MOD.PLN-PPN-LCN10-18**  
**UNIVERSAL PEELER-POTATO PEELER-MUSSEL WASHER MOD.PLN-PPN-LCN10-18**

| Rif No | Codice Code | Caratteristiche Characteristics | Descrizione Description            |
|--------|-------------|---------------------------------|------------------------------------|
| 1      | 36G6590     |                                 | Albero Shaft                       |
| 2      | 3151300     | 28x42x7                         | Paraolio Oil seal                  |
| 3      | 3190830     |                                 | Rosetta Washer                     |
| 4      | 36F0090     | 6302 2RS                        | Cuscinetto Bearing                 |
| 5      | 36G5950     |                                 | Boccola Bush                       |
| 6      | 3600870     |                                 | Fondo Bottom                       |
| 7      | 3151750     |                                 | Guarnizione Gasket                 |
| 8      | 36G6600     |                                 | Puleggia Pulley                    |
| 9      | 36G6610     | ☺ Poly V-559 j12                | Cinghia Belt                       |
| 10     | 36G6620     | (PLN-PPN10-18)                  | Puleggia Pulley                    |
| 10     | 36G0030     | (LCN10-18)                      | Puleggia Pulley                    |
| 11     | 35V1230     |                                 | Staffa Bracket                     |
| 12     | SL0010      | 5x5x20                          | Linguetta Key                      |
| 13     | SL0040      | 400V/3Ph/50Hz (PPN10)           | Motore Motor                       |
| 13     | SL0041      | 230V/1Ph/50Hz (PPN10)           | Motore Motor                       |
| 13     | SL1041      | 400V/3Ph/50Hz (PPN18)           | Motore Motor                       |
| 13     | SL1042      | 230V/1Ph/50Hz (PPN18)           | Motore Motor                       |
| 13     | SL1521      | 400V/3Ph/50Hz (LCN10)           | Motore Motor                       |
| 13     | SL1523      | 230V/1Ph/50Hz (LCN10)           | Motore Motor                       |
| 13     | SL1522      | 400V/3Ph/50Hz (LCN18)           | Motore Motor                       |
| 13     | SL1524      | 230V/1Ph/50Hz (LCN18)           | Motore Motor                       |
| 13     | 32M4080     | 400V/3Ph/50Hz (PLN10)           | Motore Motor                       |
| 13     | 32M4050     | 400V/3Ph/50Hz (PLN18)           | Motore Motor                       |
| 14     | 3140460     | ø88+ø96                         | Fascetta Clip                      |
| 15     | SL2721      | ø90 (PLN-PPN-LCN)               | Tubo Tube                          |
| 15     | 35X1150     | ø90 (PLF-PPF-LCF)               | Tubo Tube                          |
| 16     | 3151550     | ø15xø25x3                       | Guarnizione Gasket                 |
| 17     | 33M0010     | 3/4" F-F                        | Tubo Tube                          |
| 18     | 33D1371     | ☺ 230V/50-60Hz 3/4" M           | Elettrovalvola Electro-valve       |
| 19     | SL0893      | PG13,5                          | Pressacavo Cable clamp             |
| 19     | 32D0360     | 01/01/04 f.p.(*)                | Pressacavo Cable clamp             |
| 20     | 32D1090     | PG21                            | Pressaquaina Sheathing clamp       |
| 21     | SL2939      |                                 | Piastra Plate                      |
| 21     | 35Q8620     | 01/01/04 f.p.(*)                | Piastra Plate                      |
| 22     | SL2785      |                                 | Piastra Plate                      |
| 22     | 35V8601     | 01/01/04 f.p.(*)                | Divisorio Dividing head            |
| 23     | 32D0630     | 01/01/04 f.p.(*)                | Piastra Plate                      |
| 24     | SA3450      | (PTA) plastic                   | Kit disco Disk set                 |
| 25     | 6005390     | Assembly                        | Sportello Door                     |
| 26     | 35M8840     |                                 | Copertura Covering                 |
| 27     | SL2921      | ☺                               | Scheda elettronica Electronic card |
| 27     | 32Z4840     | 01/01/04 f.p.(*)                | Teleruttore Remote control switch  |
| 28     | 32W3240     | ☺                               | Microinterruttore Microswitch      |
| 29     | 33Q6210     | 1/4" M-F                        | Raccordo Nipple                    |
| 30     | 33Q6040     | L 90° 1/4" M-F                  | Raccordo Nipple                    |
| 31     | 33Q5180     | 1/4" M ø12                      | Portagomma Clutch                  |
| 32     | 33M0960     | ø12                             | Tubo Tube                          |
| 33     | 36D9660     |                                 | Saltarello Leaper                  |
| 34     | 36G2040     |                                 | Perno Pivot                        |
| 35     | 30W2930     | (PLN-PPN-LCN10)                 | Carcassa Housing                   |
| 35     | SL2694      | (PLN-PPN-LCN18)                 | Carcassa Housing                   |
| 35     | 30W3010     | 22/07/03f.p.(*) (PLN-PPN-LCN18) | Carcassa Housing                   |
| 36     | SL2695      |                                 | Fondo Bottom                       |
| 37     | 36C0011     |                                 | Telaio Frame                       |
| 38     | 37Q7860     | ☺                               | Guarnizione Gasket                 |
| 39     | 3600160     | ☺                               | Magnete Magnet                     |
| 40     | SL2494      | ☺                               | Tela abrasiva Emery cloth          |
| 41     | 6005380     | Assembly                        | Coperchio Cover                    |
| 42     | SA3400      | Assembly                        | Sportello Door                     |
| 43     | 36D9550     |                                 | Boccola Bush                       |
| 44     | SL2135      |                                 | Disco Disk                         |
| 45     | ACPTA       | Assembly                        | Disco patate Potato disk           |
| 46     | ACCI        | (PLF-PPF-LCF) Assembly          | Telaio Frame                       |
| 47     | 36M5090     |                                 | Maniglia Handle                    |
| 48     | SL2871      | ☺                               | Guarnizione Gasket                 |
| 49     | 36Z6501     |                                 | Coperchio Cover                    |
| 50     | 3600310     | ☺                               | Magnete Magnet                     |
| 51     | 35V6381     |                                 | Staffa Bracket                     |
| 52     | 32Z3030     | 01/01/04 f.p.(*)                | Scheda elettronica Electronic card |
| 53     | 30A3620     |                                 | Pannello Panel                     |
| 53     | 30A3560     | 01/01/04 f.p.(*)                | Pannello Panel                     |
| 54     | 37M4770     |                                 | Etichetta Label                    |
| 54     | SL1504      | 01/01/04f.p.(*) (PPN-LCN10-18)  | Etichetta Label                    |
| 54     | SL1505      | 01/01/04 f.p.(*) (PLN10-18)     | Etichetta Label                    |
| 55     | 36D7310     |                                 | Boccola Bush                       |
| 56     | 36Z0690     |                                 | Scatola Box                        |
| 57     | 36G6880     |                                 | Disco cozze Mussel disk            |
| 58     | 36M5250     |                                 | Pomello Knob                       |
| 59     | 6000930     | Assembly                        | Sportello Door                     |
| 60     | 6005400     | Assembly                        | Maniglia Handle                    |
| 61     | ACPPC       | Assembly                        | Disco cozze Mussel disk            |
| 62     | SL2720      | ø100-ø50                        | Riduzione Reduction                |
| 63     | SL2719      | ø50                             | Gomito Bend                        |
| 64     | 32W2970     | ☺ 230V 2W green                 | Lampada Lamp                       |
| 65     | 32W3280     | ☺ 230V 2W white                 | Lampada Lamp                       |
| 66     | SL2348      | ☺                               | Timer Timer                        |
| 67     | SL1539      | ☺ Unstable                      | Pulsante Push button               |

(\*): fuori produzione / out of production

☺: ricambio consigliato / spare part suggested