


+7(812)987-08-81




Model	All									
Table	SP TR260		Page	2		Exploded view Casing+ tactile control				
Pos.	Spare Part	Alias Code	Repl. by	S	Info	Kit	Techn. Bulletin	Description	Notes	
0001	0H1034			S	A			CAPACITOR; 200MF		
0002	0D3491				D			YOKE 100X16 (SET X6)		
0003	0D5632				D			BOITIER FEMELLE; 9V 003507821		
0004	0D2848							PRINTED CIRCUIT FIXING SPACER (SET X6)		
0005	0D5754				D			SUPPORT; TR260		
0006	000000								See S2	
0007	0D3941							CABLE; 3PH		
0007	0D5645							SUPPLY CABLE; UL TRI K120/180		
0007	0D6097							CORDON ALIMENTATION MONO TR260		
0008	0D2073							STUFFING BOX ASSY PL-CD4/8/13		
0009	0D5755							CONTAINER; CI TR260		
0010	0D5756				D			CONTROL PANEL; 1V TR260		
0010	0D5757				D			CONTROL PANEL; 2V TR260		
0010	0D5758				D			CONTROL PANEL; 2V US TR260		
0011	0D5633				D			SPACER; CI (JEU X10)		
0012	000000								See S4	
0013	0D5188							WASHER; PE M3; 10 PCS		
0014	0D5404	33987	033987					NUT; HU M3 (JEU10)		
0015	0D0506				D			SCREW; 10 PCS		
0016	0D2297				D			WASHER CS M5 SET X10		
0017	0D6042				D			PORTE SECURITE TR250		
0018	0KQ281		0D5191		A			SENSOR		
0019	000000	33986								
0019	0D0608							SCREW; 10 PCS		
0019	0D2877							WASHER GALVA STL3 SET X10		
0019	0D5404	33987	033987					NUT; HU M3 (JEU10)		
0020	0KQ592				D			SWITCH		
0021	0D0946				D			GROMMET; 10 PCS		
0022	0D0594							SCREW; 10 PCS		
0023	0D2321							SCREW; SET 10PCS; M4X20		
0023	0D3065							NUT HU M4 WRAPPED (SET X10)		
0023	0D6441				K	Kit		SPACER; SET 10PCS; 4X10X10		
00S1	0D5759				D			SUPPORT; MONO TR260		
00S1	0D5760							SUPPORT; TRI TR260		
00S2	0D5679			S				POWER BOARD; 2V EQ TBX		
00S2	0KQ429			S	A			POWER BOARD; 1-P 220/240V-50/60HZ		

Model		All							
Table		SP TR260		Page	2	Exploded view Casing+ tactile control			
Pos.	Spare Part	Alias Code	Repl. by	S	Info	Kit	Techn. Bulletin	Description	Notes
00S3	0D5761				D			CONTAINER; EQ 1V TR260	
00S3	0D5762				D			CONTAINER; EQ 2V STD TR260	
00S3	0D5763				D			CONTAINER; EQ 2V USA TR260	
00S4	0D5764							CARD; CDE 1V COMPLETE TR260	
00S4	0D5765							CARD; CDE 2V COMPLETE TR260	
00S5	0D5766				D			BRACKET; EQ TR260	



Model	All									
Table	SP TR260		Page	6		Exploded view Mechanism				
Pos.	Spare Part	Alias Code	Repl. by	S	Info	Kit	Techn. Bulletin	Description	Notes	
0025	0KQ674			S	A			EJECTOR		
0026	0KQ534			S				EJECTOR DRIVING		
0027	000000								See S6	
0028	0D3533			S				LIPPED SEAL 35X62X7 (SET X5)		
0029	0D0006			S				BEARING		
0030	0D0004			S				BEARING; 6008 2RS		
0031	0D0915							TR260 DRIVE PULLEY ASSY		
0032	0KJ743			S	A			BELT		
0033	0D3035							SLOTTED NUT M25 (SET X5)		
0034	0HD003							LOCK WASHER; 5 PCS		
0035	0D0003							PULLEY		
0036	0D2915							WEDGE A 6X6X38 (X10)		
0037	0KQ697							PIN		
0038	0KQ516							PIN; 10 PCS		
00S6	0KQ676				A			SHAFT		
00S7	0D0913			S				TR260 COMPLETE DRIVE MECHANISM		
00S8	0D0914							TR260 DRIVEN PULLEY ASSY		



Model		All							
Table		SP TR260		Page	8	Exploded view Body			
Pos.	Spare Part	Alias Code	Repl. by	S	Info	Kit	Techn. Bulletin	Description	Notes
0S10	0D6098				D			PLAQUE FERMETURE EQ TR260	
0S11	0D5769				D			FOOD; EQ TR260 (JEU X4)	
0S12	0D6402							LOCK BOLT; NM EQ TR260	
0S13	0KQ673				A			KNOB WITH BAR	

**Nomenclature trémie standard / Parts list hopper /
Stückliste - Standardtrichter / Nomenclatura - Tramoggia
standard / Nomenclatura - Tolva estándar**

S15




Page 9 of 14

Model	All									
Table	SP TR260		Page	12		Parts list hopper				
Pos.	Spare Part	Alias Code	Repl. by	S	Info	Kit	Techn. Bulletin	Description	Notes	
0070	0D2657							LEVER STD ASSY TR260		
0071	0D0027				D			CAP COVER		
0072	0D5773							SHUTTER ASSEMBLY; EQ TR260		
0073	0D0110							TR250 EQUIPPED BRACKET		
0074	0D5774							GASKET; PROFILE EQ TR260		
0075	0KJ761				A			FEEDSTICK ASSEMBLY TR250		
0076	0U0482							COVER HANDLE & STUD		
0077	0D0911							TR260 NUT PAD ASSEMBLY		
0078	0KJ010			S	A			BUSHING		
0079	0KQ699							LIMIT STOP/THRUST BEARING; 5 PCS		
0080	0D2659				D			PRESSER STD ASSY TR260		
0081	0KJ599			S	A			BUSHING; 5 PCS		
0082	0D2660							PIVOT SHAFT ASSY TR260		
0083	0KJ062			S	A			MAGNET; 8X35		
0084	0D0031			S				BUSH		
0085	0D0912							SPRING; 2 PCS		
0086	0D2658							LINK ROD ASSY TR260		
0087	0D0029				D			PIN		
0S15	0D5488							LEVER; COMPLETE EQ TR260		

Зип Общепит

**Vue éclatée trémie choux / Exploded view hopper /
Explosionszeichnung - Kohltrichter / Esploso - Tramoggia
cavoli / Despiece - Tolva coles**

+7(812)987-08-81



N



TR 260 FR 05 06

Model	All									
Table	SP TR260		Page	14	Exploded view hopper					
Pos.	Spare Part	Alias Code	Repl. by	S	Info	Kit	Techn. Bulletin	Description	Notes	
0090	0D5776				D			LEVER; EQ TR260		
0091	0D0912							SPRING; 2 PCS		
0092	0D2658							LINK ROD ASSY TR260		
0093	0D0031			S				BUSH		
0094	0KJ062			S	A			MAGNET; 8X35		
0095	0D2660							PIVOT SHAFT ASSY TR260		
0096	0D5777				D			FRAME ASSEMBLY; EQ TR260		
0097	0KJ599			S	A			BUSHING; 5 PCS		
0098	0KQ699							LIMIT STOP/THRUST BEARING; 5 PCS		
0099	0D1570				D					
0100	0D0911							TR260 NUT PAD ASSEMBLY		
0101	0U0482							COVER HANDLE & STUD		
0102	000000	21038								

Зип Общепит

Vue éclatée trémie choux / Exploded view Automatic
Hopper / Explosionszeichnung - Automatischer Trichter /
Esploso - Tramoggia automatica / Despiece - Tolva automática

+7(812)987-08-81



Model		All									
Table		SP TR260		Page		16		Exploded view Automatic hopper			
Pos.	Spare Part	Alias Code	Repl. by	S	Info	Kit	Techn. Bulletin	Description	Notes		
0105	0D5778							CHARGEUR; EQ TR260			
0106	0D3222							MAGNET HOLDER ASSY CRUDITO			
0107	0D5779				D			RAMPE; EQ TR260			
0108	0D2656							AGITATOR ASSY TR260			
0109	000000	23794									